POWERLINK Design Tool

Overview

The POWERLINK *Design Tool* is a tool for the rapid and cost-saving development of **Ethernet Power-LINK** applications (devices). It administers device databases, from which an object dictionary and an initialization function in C-code, an Electronic Data Sheet (XML format) and the documentation are produced automatically. Furthermore it simplifies the configuration of the POWERLINK *Library* and of the *POWERLINK Driver Packages*.



Description

With the POWERLINK *Design Tool* a tool is available, which frees the developer from error-prone and repetitive tasks. It guarantees the consistency of the implemented functionality, device documentation and XML Device Description (XDD). By default the POWER-LINK communication profile is delivered with the tool.

In addition to the POWERLINK specific communication database other databases are provided for the CANopen device profiles CiA 401, CiA 402, CiA 406 and CiA 417. The object dictionary produced by the POW-ERLINK *Design Tool* supports numerous options of the POWERLINK *Library* from *port*, e.g. segmented structuring. A tree representation of all implemented parameters and data facilitates the maintenance of the device software. The POWERLINK *Design Tool* eases the first step into the POWERLINK protocol and device development is accelerated. It is a tool with which device databases can be produced and processed. These databases contain information, which describe the interface for the POWER-LINK network of the device. These parameters, control and status information that are accessible over the network are stored in the **Object dictionary**.

The major task of the POWERLINK *Design Tool* is to administer and create these data in an object database and to create code for the POWERLINK *Library* from it.

Ethernet POWERLINK Object dictionary

The generated code, which contains the object dictionary is included into the user modules. This ensures that each user variable can be accessed directly via its index and sub index. The produced object dictionary represents the data interface between library and user application.

Ethernet POWERLINK Library Configuration

To configure the POWERLINK *Library* a header file is created which contains the hardware settings and the configuration of the used POWERLINK services. These services are derived automatically from the object dictionary.

XML Device Description File

A fourth result of the tool is the XML Device Description File (XDD). The XDD belongs to the standard documents that have to be supplied with a POWERLINK device. It is an XML text file according to ISO 15745, which contains all relevant information about the application (device). These files are used by configuration tools and control devices, in order to install POWERLINK devices into networks and configure them. The

Documentation

On the generated object dictionary a documentation is created. Each device parameter is listed with its attributes and description. Output format is HTML and plain text. This documentation can serve as specification at the beginning of development and be brought into the user documentation, as well as into the marketing documents.



Device Profiles

Creating of device databases is very simple. The first step is determining the type of the device. If a standardized profile is to be implemented, then the device data can be loaded from a profile database. Furthermore it is possible to load data from device databases or already existing XDD or EDS files. CANopen EDS files can be imported.

Indices Groups Select objects: Groups Select objects: Groups Group	Import File	×
Good Read State 8 Input Lines Good Polarity 8 Input Lines Good Input Interrupt Mask 8 - any c Good Input Interrupt Mask 8 - low t Good Polarity 1 Input Line 1-128 Good Interrupt Mask 1 Input Line 1 Good Polarity 16 Input Lines Good Polarity 16 Input Lines Good Polarity 16 Input Lines Good State 32 Input Lines Good State 33	Indices Groups	
 6002 Polarity 8 Input Lines 6003 Filter Constant 8 Input Lines 6005 Enable Digital Input Interrupt 6006 Input Interrupt Mask 8 - any c 6007 Input Interrupt Mask 8 - low t 6008 Input Interrupt Mask 8 - low t 6008 Input Interrupt Mask 8 - high 6020 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1 6060 Interrupt Mask 1 Input Line 1 6010 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Mak Offset 	Select objects:	
 6003 Filter Constant 8 Input Lines 6005 Enable Digital Input Interrupt 6006 Input Interrupt Mask 8 - any c 6007 Input Interrupt Mask 8 - low t 6008 Input Interrupt Mask 8 - high 6000 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1- 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines 6123 Filter Constant 32 Input Lines 	E 6000 Read State 8 Input Lines	
6005 Enable Digital Input Interrupt 6006 Input Interrupt Mask 8 - any c 6007 Input Interrupt Mask 8 - low t 6008 Input Interrupt Mask 8 - high 6020 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1 6060 Interrupt Mask 1 Input Line 1 6070 Interrupt Mask 1 Input Line 1 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines 6123 Filter Constant 32 Input Lines	🗄 🛅 6002 Polarity 8 Input Lines	
 6006 Input Interrupt Mask 8 - any c 6007 Input Interrupt Mask 8 - low t 6008 Input Interrupt Mask 8 - high 6020 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1 6060 Interrupt Mask 1 Input Line 1 6070 Interrupt Mask 1 Input Line 1 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Mathematical State 16 Input Lines 6123 Filter Constant 32 Input Lines 	🕀 💼 6003 Filter Constant 8 Input Lines	
 6007 Input Interrupt Mask 8 - low t 6008 Input Interrupt Mask 8 - high 6020 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Mathematical State 16 Input Lines 6123 Filter Constant 32 Input Lines 	6005 Enable Digital Input Interrupt	
 6008 Input Interrupt Mask 8 - high 6020 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1- 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Mathematical State 32 Input Lines 6123 Filter Constant 32 Input Lines 6123 Filter Constant 32 Input Lines 	🕀 📄 6006 Input Interrupt Mask 8 - any c	
 6020 Read State 1 Input Line 1-128 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1- 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Mask 06102 	🕀 💼 6007 Input Interrupt Mask 8 - low t	
 6030 Polarity 1 Input Line 1-128 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1- 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines 	🖻 🖻 6008 Input Interrupt Mask 8 - high 📹	
 6038 Filter Constant 1 Input Line 1 6050 Interrupt Mask 1 Input Line 1- 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines 	🕀 💼 6020 Read State 1 Input Line 1-128	
 6050 Interrupt Mask 1 Input Line 1- 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Mask Offset: 	🕀 💼 6030 Polarity 1 Input Line 1-128	
 6060 Interrupt Mask 1 Input Line 1- 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Make Offset: 		
 6070 Interrupt Mask 1 Input Line 1- 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Index Offset: 	· · ·	
 6100 Read State 16 Input Lines 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Index Offset: 		
 6102 Polarity 16 Input Lines 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Index Offset: 	· · ·	
 6103 Filter Constant 16 Input Lines 6106 Input Interrupt Mask 16 Input 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Index Offset: 		
 G106 Input Interrupt Mask 16 Input G107 Input Interrupt Mask 16 Input G108 Input Interrupt Mask 16 Input G120 Read State 32 Input Lines G122 Polarity 32 Input Lines G123 Filter Constant 32 Input Lines Index Offset: 		
 6107 Input Interrupt Mask 16 Input 6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Index Offset: 		
6108 Input Interrupt Mask 16 Input 6120 Read State 32 Input Lines 6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Machine Mathematical Index Offset:		
Image: Constant set of the set of t		
6122 Polarity 32 Input Lines 6123 Filter Constant 32 Input Lines Model		
6123 Filter Constant 32 Input Lines Note: Ox0800		
Index Offset: 0x0800		
Import Cancel	Index Onser.	
,	Import Cancel	
	·	2

Import mask for a profile database

The second step is the parameterization of the objects. Pre-installed default values, limit values and access attributes have to be adapted to the application needs. For the communication parameters input masks facilitate the creation of the service objects and the configuration of partially bit-coded values like e.g. PDO settings.

Generation

After an automatic check of the data for consistence, missing entries or incompatible data types the following files are created:

- the object dictionary (objects.h),
- the configuration file (**epl_conf.h**),
- the XML Device Description file
- and documentation as HTML and plain text.

Profile Databases

The profile databases contain the objects of the corresponding profile. Each object is configured according to the standard and is explained in detail. By importing these prefabricated objects into the own project the development time can be reduced and the risks of a manual implementation are minimized.

The following profile databases currently available:

- CiA401 Device Profile for Generic I/O Devices
- CiA402 Device Profile for Drives and Motion Control
- CiA417 Application Profile for Lift Control Systems

POWERLINK-Merge

The optionally available POWERLINK-Merge PlugIn is a tool to compare and to merge POWERLINK *Design Tool* projects. A detailed presentation of each attribute of indices and sub indices and comfortable editing facilities simplify the handling of multiple projects. The integrated diff report generator generates expressive diff reports in XML.



POWERLINK-Merge shows its strength especially when dealing with large projects or with large development teams.

-2-



Advantages

- acceleration of the development by avoidance of double work
- error prevention during creation of the object dictionary and XDD
- consistent documentation to the respective device version
- reuse of the data for similar devices
- optimized configuration of the POWERLINK *Library* according to the implemented POWERLINK services
- optional CSV import PlugIn available

System Environment

The POWERLINK Design Tool runs on PC's with

- Operating System: Windows[™] 2000, XP, Vista, Win7 and LINUX[™]
- Processor: Pentium III or later
- RAM: > 256 MB, HD > 20 MB free

Ordering Information

1760/10	POWERLINK-DT-W
	(Full Version Windows TM)
1760/20	POWERLINK-DT-L
	(Full Version LINUX TM)
0640/11	CANopen-DT-P401
	profile database for CiA401
0640/12	CANopen-DT-P402
	profile database for CiA402
0640/13	CANopen-DT-P406
	profile database for CiA406
0640/30	CANopen-DT-P417
	profile database for CiA417
0640/24	CANopen-DT-P405
	Profildatenbank for CiA405
0640/26	CANopen-DT-P410
	Profildatenbank for CiA410
0640/28	CANopen-DT-P418
	Profildatenbank for CiA418
0640/29	CANopen-DT-P419
	Profildatenbank for CiA419
0640/30	CANopen-DT-P417
	Profildatenbank for CiA417
0640/32	CANopen-DT-P447
	Profildatenbank for CiA447



0640/33	CANopen-DT-P452
	Profildatenbank for CiA452
0640/49	CANopen-DT-CAN-Merge
	CAN-Merge PlugIn
0640/52	CANopen-DT-CSV
	CSV-Import PlugIn

Functional demo versions of the software tools are available for download on *www.port.de/shop*.

Engineering Services

port is providing engineering services and trainings for our business activities:

- CAN and CAN-based protocols: CANopen, J1939
- Industrial Ethernet Protocols: POWERLINK, Ether-Net/IP, EtherCAT PROFINET
- Implementation of devices according to CANopen device profiles
- VHDL based solutions for industrial applications
- application specific implementations or enhancements
- embedded LINUX projects

Notice

Brands and product names are trademarks or registered trademarks of their respective companies. The product will be continuously improved. *port* therefore reserves the right to change technical properties at any time without appointment.





关注我们

需要详细信息?请通过sales@hkaco.com联系我们 | 电话: 400-999-3848 **办事处:** 广州 | 北京 | 上海 | 深圳 | 西安 | 武汉 | 成都 | 沈阳 | 香港 | 台湾 | 美国 **-3-**